

BGC2000 Parts List

Diagram Number	Part Number	Description	Material	Qty/set
1	C2000-1	Hose connector	ABS	1
2	C2000-2	Dust container	ABS	1
3	C2000-3	HEPA filter	ABS	1
4	C2000-4	Cover for dust container	ABS	1
5	C2000-5	Seal for dust container	PVC	1
6	C2000-6	Pre-motor filter		1
7	C2000-7	Holder for pre-motor filter	ABS	1
8	C2000-8	Seal for filter holder	PVC	1
9	C2000-9	Rubber seal for motor	Rubber	1
10	C2000-10	Motor		1
11	C2000-11	Rubber support for motor	Rubber	1
12	C2000-12	Exhaust cover	ABS	1
13	C2000-13	Lock for rear cover	ABS	1
14	C2000-14	Spring	ABS	1
15	C2000-15	Rear cover	ABS	1
16	C2000-16	Lock for dust container	ABS	1
17	C2000-17	Switch		1
18	C2000-18	Spring	Steel	1
19	C2000-19	Right body	ABS	1
20	C2000-20	Wheel	PP	2
21	C2000-21	Power cord stopper	ABS	1
22	C2000-22	Left body	ABS	1
23	C2000-23	Power cord		1
24	C2000-24	Active wheel	ABS	1
25	C2000-25	Small wheel	ABS	1
26	C2000-26	Hose		1
27	C2000-27	Plastic wand		2
28	C2000-28	Floor brush		1
29	C2000-29	Crevice nozzle		1
30	C2000-30	Upholstery nozzle		1
31	C2000-31	Round brush		1
32	C2000-32	Accessory holder		1

BGC2000 Parts List

